
Getting Started to connect FOX PRO

Wireless / BT / Wired Gaming Headset



Scan the QR code to downlod complete user manual on www.whiteshark.gg


2.4 GHz Wireless connection
Plug one of the two dongles (USB or USB-C) into your PC or console.
Power on the headset: Press and hold the power button for 3 seconds.

2.4 GHz Pairing: The indicator light will flash green: the headset is ready to connect.
Successful connection: The light turns solid green: the 2.4 GHz connection is established.

Note: When connecting to a PC for the first time, a new device will be detected. Restart if necessary.
If you encounter any issues: Check the dongle / Turn the headset off and on again / Try another USB port / Restart the computer / Recharge the headset.


BT connection
Power on the headset: Press and hold the power button for 3 seconds. BT mode: Quickly double-click the power button. The indicator light will flash blue. Activate BT on your device: Open the BT settings on your console, phone, tablet, or PC. Search and connect: Look for"FOX PRO" and select it. Successful connection: The light turns solid blue.
If you encounter any issues: Turn BT off and on again / Restart the headset / Remove "FOX PRO" from your device and pair again / Check that the headset is charged.

3.5 mm wired connection




Switch to wired mode when the battery is empty using the 3.5 mm jack connection.

① Power Button/Wireless Modes
② Headband
③ Volume ±
④ 3.5 mm Jack Port (4-pin)
⑤ Microphone Mute
⑥ Status Indicators (BT / 2.4 GHz)
⑦ Microphone Port
⑧ Detachable Microphone
⑨ USB Type-C Charging Port
⑩ Charging Indicator
⑪ Dual Dongle (USB & USB Type-C)



A single press toggles the microphone on or off.




Enjoy up to 40 hours of battery life. Easily recharge your headset using the included USB-C to USB-A cable. Full charge time: 2h 30 min.

WHITE SHARK

Upute za spajanje

FOX PRO

Wireless / BT / Žične
Gaming slušalice



Skenirajte QR kod za preuzimanje potpunog korisničkog priručnika na www.whiteshark.gg


2.4 GHz Bežično povezivanje
Uključite jedan od dva prijamnika (USB ili USB-C) u vaše računalo ili konzolu.
Uključite slušalice: pritisnite i držite tipku za uključivanje 3 sekunde.

Uparivanje 2.4 GHz: indikator će treptati zeleno – slušalice su spremne za povezivanje.
Uspješno povezivanje: svjetlo stalno svijetli zeleno – 2.4 GHz veza je uspostavljena.

Napomena: Prilikom prvog povezivanja s računalom, bit će prepoznat novi uređaj. Po potrebi ponovno pokrenite računalo. Ako naiđete na probleme: Provjerite dongle / Isključite i ponovno uključite slušalice / Pokušajte s drugim USB priključkom / Ponovno pokrenite računalo / Napunite slušalice.


BT povezivanje
Uključite slušalice: pritisnite i držite tipku za uključivanje 3 sekunde. BT način rada: brzo dvaput pritisnite tipku za uključivanje. Indikator će treptati plavo. Aktivirajte BT na svom uređaju: otvorite BT postavke na konzoli, telefonu, tabletu ili računalu. Pretražite i povežite: pronađite "FOX PRO" i odaberite ga. Uspješno povezivanje: svjetlo stalno svijetli plavo.
Ako naiđete na probleme:
Isključite i ponovno uključite BT / Ponovno pokrenite slušalice / Uklonite "FOX PRO" s uređaja i ponovno uparite / Provjerite jesu li slušalice napunjene.

3,5 mm žično povezivanje




Prebacite na žični način rada kada je baterija prazna koristeći 3,5 mm priključak.

① ON/OFF tipka / Bežični načini rada
② Traka za glavu
③ Glasnoća ±
④ 3.5 mm priključak (4-pinski)
⑤ Isključivanje mikrofona
⑥ Statusni indikatori (BT / 2.4 GHz)
⑦ Priključak za mikrofon
⑧ Odvojivi mikrofon
⑨ USB Type-C priključak za punjenje
⑩ Indikator punjenja
⑪ Dvostruki prijamnik (USB i USB Type-C)



Kratki pritisak na tipku uključuje ili isključuje mikrofon.



Uživajte u do 40 sati trajanja baterije. Jednostavno napunite slušalice pomoću priloženog USB-C na USB-A kabela. Vrijeme potpunog punjenja: 2 h 30 min.