

  BGM-13 MORAY ULTRA LIGHTWEIGHT WIRELESS GAMING MOUSE User manual	ABOUT THE MORAY - ULTRA LIGHTWEIGHT WIRELESS GAMING MOUSE Before using this product, carefully read this manual and any manuals for compatible hardware. Retain instructions for future reference.	CHARGING INDICATOR LIGHT The red light under the middle scroll wheel stays on while charging and light off when fully charged.	EXTERIOR PROTECTION Follow the instructions below to help prevent the product exterior from deteriorating, scratching, or becoming discolored. • Do not place rubber, vinyl, or plastic materials in prolonged contact with the mouse exterior, as this may cause surface damage or discoloration. • Do not expose the mouse to direct sunlight for extended periods. • Avoid contact with oils, lotions, sweat buildup, or chemicals that may affect the surface finish. • Do not use alcohol, benzene, thinner, ammonia-based cleaners, or abrasive cleaning agents. • Do not use chemically treated cleaning cloths. • To clean the product, use a soft, dry microfiber cloth. • If necessary, lightly dampen the cloth with clean water only. Make sure the product is powered off and completely dry before use. • Do not allow moisture to enter openings such as the scroll wheel gap, bottom sensor area, USB receiver slot, or Type-C charging port. • Store the product in a dry, dust-free environment when not in use.	 BGM-13 MORAY ULTRA LIGHTWEIGHT WIRELESS GAMING MOUSE 
	SPECIFICATIONS • Mouse type: Ultra Lightweight Wireless Gaming Mouse • Chipset: Instant S201B • Interface: 2.4 G + BT Dual - Mode Wireless Mouse • Sensor type: Instant S201B • Resolution: 3200 DPI (Adjustable) • Polling rate: 125 / 133 Hz (BT) • Track speed: 40 IPS • Acceleration: 10 G • Keys Lifetime: HUANO 3 million left and right switches • Software: No • Illumination: No • Cable length: 30 cm USB A to Type-C PVC Cable • Dimensions: 120 mm x 38 mm x 61 mm • Weight: 65g ± 3 g • Compatibility: Windows 7 / 8 / 10, Windows XP, Vista, Mac OS • Color: Pink • Material: ABS • Battery: 500mAh rechargeable Li-ion battery • Working Hours: 25 h	USE AND HANDLING PRECAUTIONS • Avoid prolonged continuous use of the mouse. Take a break approximately every 30 minutes to prevent hand fatigue. • Stop using the mouse immediately if you experience discomfort, pain, numbness, or tingling in your hands, wrists, or arms. If symptoms persist, consult a medical professional. • This product is intended for hand use only. • Do not use excessive force when clicking buttons or pressing the scroll wheel. • The ultra-lightweight design (approx. 65 g) allows extended use, but improper posture may still cause strain. Maintain a natural wrist position while using the mouse. • Do not disassemble or attempt to modify the product. • Do not expose the mouse to high temperatures, high humidity, direct sunlight, or open flame. • Do not allow the product to come into contact with liquids. If liquid enters the device, stop using it immediately. • Do not place heavy objects on the mouse. • Do not throw, drop, or subject the product to strong physical impact. • When using the 2.4 G wireless USB receiver, ensure it is properly inserted into the USB port to prevent damage. • When switching between 2.4 G / OFF / BT modes, move the bottom switch gently to avoid damage. • Use only the included Type-C charging cable or a certified equivalent. • Do not charge the mouse near flammable materials. • The rechargeable Li-ion battery (500 mAh) must not be disassembled, punctured, or exposed to excessive heat. • Disconnect the product during thunderstorms or long periods of non-use. • Keep the product out of reach of small children. Small parts (USB receiver) may present a choking hazard.	BATTERY LIFE AND DURATION • Do not handle, use, or charge a damaged, swollen, or leaking Lithium-ion battery. • The built-in rechargeable Li-ion battery (500 mAh) has a limited lifespan. Battery capacity will gradually decrease with repeated charging cycles and age. • Battery performance may vary depending on usage patterns, wireless mode (2.4 G or Bluetooth), environmental temperature, and storage conditions. • Charge the mouse only in an environment with an ambient temperature between 10° C – 30° C (50° F – 86° F). Charging outside this range may reduce efficiency or affect battery lifespan. • Use only the supplied Type-C charging cable or a certified equivalent. • Do not expose the battery to excessive heat, open flame, direct sunlight, or temperatures above 40° C. • Do not disassemble, puncture, crush, or attempt to replace the internal battery. • Do not short-circuit the charging port or allow metal objects to contact it. • If the product will not be used for an extended period, charge it at least once every 6–12 months to help maintain battery health. • Stop using the product immediately if you notice unusual heat, odor, discoloration, deformation, or performance issues. • Dispose of the product in accordance with local electronic waste and battery disposal regulations.	
	CONNECTION MODE 2.4 G mode Take out the 2.4 G USB dongle from the mouse USB slot, plug the 2.4 G USB dongle into free USB port of the computer, 2.4 G pairing time: about 30 seconds, after successfully connection, then can be use normally. BT mode 1. Bluetooth indicator flashes blue light at the bottom of the mouse 2. Dial the bottom switch to BT position, turn on the BT on your computer, and search the BT name"Moray" to and connect. After fully connection, then can use BT mode.			

  BGM-13 MORAY ULTRA LAGANI BEŽIČNI GAMING MIŠ Upute	O MODELU MORAY – ULTRA LAGANI BEŽIČNI GAMING MIŠ Prije korištenja ovog proizvoda pažljivo pročitajte ovaj priručnik te priručnike za kompatibilnu opremu. Upute sačuvajte za buduću uporabu.	INDIKATOR PUNJENJA Crveno svjetlo ispod središnjeg kotačića svijetli tijekom punjenja, a gasi se kada je baterija u potpunosti napunjena.	ZASTIITA VANJSKOG KUĆIŠTA Slijedite upute u nastavku kako biste spriječili oštećenje, ogrebotine ili promjenu boje vanjske površine proizvoda. • Ne ostavljajte gumene, vinilne ili plastične materijale u dugotrajnom kontaktu s kućištem miša jer to može uzrokovati oštećenje ili promjenu boje površine. • Ne izlažite miš dugotrajno izravnoj sunčevoj svjetlosti. • Izbjegavajte kontakt s uljima, losionima, nakupljenim znojem ili kemikalijama koje mogu utjecati na površinsku obradu. • Ne koristite alkohol, benzin, razrjeđivače, sredstva na bazi amonijaka niti abrazivna sredstva za čišćenje. • Ne koristite kemijski tretirane krpe za čišćenje. • Za čišćenje proizvoda koristite mekanu, suhu krpu od mikrofibre. • Po potrebi prou lagano navlažite isključivo čistom vodom. Provjerite je li uređaj isključen i potpuno suh prije ponovne uporabe. • Ne dopustite da vlaga uđe u otvore poput prostora oko kotačića, područja senzora na donjoj strani, utora za USB prijemnik ili Type-C priključka za punjenje. • Kada se ne koristi, proizvod čuvajte na suhom mjestu bez prašine.	
	SPECIFICATIONS • Tip miša: Ultra lagani bežični gaming miš • Čipset: Instant S201B • Sučelje: 2.4G + Bluetooth (dual-mode) bežična veza • Tip senzora: Instant S201B • Rezolucija: 3200 DPI (podesivo) • Frekvencija osvježavanja: 125 Hz (2.4G) / 133 Hz (Bluetooth) • Brzina praćenja: 40 IPS • Ubrzanje: 10 G • Trajnost tipki: HUANO prekidači – 3 milijuna klikova (lijeva i desna tipka) • Softver: Nije potreban • Osvjetljenje: Nema • Duljina kabela: 30 cm USB-A na Type-C PVC kabel • Dimenzije: 120 x 38 x 61 mm • Težina: 65 g ± 3 g • Kompatibilnost: Windows 7 / 8 / 10, Windows XP, Vista, Mac OS • Boja: Roza • Materijal: ABS plastika • Baterija: Punjiva Li-ion baterija 500 mAh • Radno vrijeme: Do 25 sati	MJERE OPREZA PRI KORIŠTENJU • Izbjegavajte dugotrajno neprekidno korištenje miša. Napravite pauzu približno svakih 30 minuta kako biste spriječili umor ruke. • Odmah prestanite koristiti miš ako osjetite nelagodu, bol, utrnulost ili trnce u šakama, zapešćima ili rukama. Ako simptomi potraju, obratite se liječniku. • Proizvod je namijenjen isključivo za korištenje rukom. • Ne primjenjujte prekomjernu silu prilikom pritiska tipki ili kotačića. • Ultra lagani dizajn (približno 65 g) omogućuje dulje korištenje, no nepravilno držanje može uzrokovati naprezanje. Održavajte prirodan položaj zapešća tijekom korištenja miša. • Ne rastavljajte i ne pokušavajte preinačiti proizvod. • Ne izlažite miš visokim temperaturama, visokoj vlazi, izravnoj sunčevoj svjetlosti ili otvorenom plamenu. • Ne dopustite da proizvod dođe u kontakt s tekućinama. Ako tekućina uđe u uređaj, odmah ga prestanite koristiti. • Ne stavljajte teške predmete na miš. • Ne bacajte, ne ispuštajte i ne izlažite proizvod jakim fizičkim udarcima. • Prilikom korištenja 2.4 G bežičnog USB prijemnika provjerite je li pravilno umetnut u USB priključak kako bi se spriječilo oštećenje. • Prilikom prebacivanja između 2.4 G / OFF / BT načina rada, donji prekidač pomičite pažljivo kako biste izbjegli oštećenje. • Koristite isključivo priloženi Type-C kabel za punjenje ili certificiranu zamjenu. • Ne punite miš u blizini zapaljivih materijala. • Punjiva Li-ion baterija (500 mAh) ne smije se rastavljati, probijati niti izlagati prekomjernoj toplini. • Isključite proizvod tijekom grmljavine ili duljih razdoblja nekorištenja. • Držite proizvod izvan dohvata male djece. Mali dijelovi (USB prijemnik) mogu predstavljati opasnost od gušenja.	TRAJANJE BATERIJE • Ne rukujte, ne koristite i ne punite oštećenu, napuhnutu ili bateriju koja curi (Li-ion). • Ugrađena punjiva Li-ion baterija (500 mAh) ima ograničen vijek trajanja. Kapacitet baterije postupno se smanjuje s ponovljenim ciklusima punjenja i starenjem. • Trajanje baterije može varirati ovisno o načinu korištenja, bežičnom načinu rada (2.4 G ili Bluetooth), temperaturi okoline i uvjetima pohrane. • Puniti miš isključivo u okruženju s temperaturom između 10 °C – 30 °C (50 °F – 86 °F). Punjenje izvan tog raspona može smanjiti učinkovitost ili utjecati na vijek trajanja baterije. • Koristite isključivo priloženi Type-C kabel za punjenje ili certificiranu zamjenu. • Ne izlažite bateriju prekomjernoj toplini, otvorenom plamenu, izravnoj sunčevoj svjetlosti niti temperaturama iznad 40 °C. • Ne rastavljajte, ne probijajte, ne drobite i ne pokušavajte zamijeniti internu bateriju. • Ne uzrokuje kratki spoj na priključku za punjenje niti dopustite kontakt metalnih predmeta s njim. • Ako proizvod nećete koristiti dulje vrijeme, napunite ga najmanje jednom svakih 6–12 mjeseci radi očuvanja stanja baterije. • Odmah prestanite koristiti proizvod ako primijetite neobičajeno zagrijavanje, miris, promjenu boje, deformaciju ili probleme u radu. • Proizvod odložite u skladu s lokalnim propisima o zbrinjavanju elektroničkog otpada i baterija.	
	NAČIN POVEZIVANJA 2.4 G način rada Izvadite 2.4G USB prijemnik iz utora na donjoj strani miša. Umetnite 2.4G USB prijemnik u slobodan USB priključak na računalu. Proces povezivanja traje približno 30 sekundi. Nakon uspješnog povezivanja miš je spreman za normalno korištenje. BT način rada 1. Indikator Bluetooth veze treperi plavim svjetlom na donjoj strani miša. 2. Otkrenite donji prekidač u BT položaj, uključite BT na računalu te potražite BT naziv,"MORAY" i povežite se. Nakon potpunog povezivanja može se koristiti BT način rada.	WARRANTY CARD / JAMSTVENI LIST ITEM/MODEL: Naziv/model proizvoda: RECEIPT NO. / DATE OF PURCHASE: Broj i datum računa: SELLING SPOT (COMPANY): Prodajno mjesto: THE CUSTOMER: Kupac: WARRANTY PERIOD (MONTHS): Jamstveni rok (Mjesec): 24 SIGNATURE / STAMP: Potpis i pečat: All Baracuda products are examined and tested after each stage of the production process and have all the required certificates (EMC, CE,...). The products are subject to the following warranty conditions: • The warranty period for Baracuda products is 24 months (batteries 6 months) and begins on the day of being sold in the store • The warranty can only be claimed upon presentation of the original purchase invoice and a filled warranty paper with a stamp from the store it was bought at, and if the product has original packaging and all components and equipment • All malfunctioning of the product resulting from factory defects, that occur during the warranty period, and in the normal use of the product in compliance with all instructions will be removed. This warranty covers only defects in material and production. • If the product malfunctions during the warranty period, your Baracuda distributor will give you the product (afterwhich is checked by a professional) repaired or replaced • If the repair at the authorized service center is not completed within 30 days of being received at the service center, we will replace the product with a new one. If the repair during the warranty period lasts longer than 15 days, the warranty period is extended by as many days as the repair lasted. • If the device needs to be repaired within the warranty period, contact the store where you bought the product. If the product has to be sent to an authorized service center or general distributor, please send the product (with all parts and accessories) in the original packaging and with all the necessary documents (invoice, warranty card, etc.). The product can be repaired only in the authorized service center of the importer. The costs of shipping the product to the service center are funded by the customer. Possible damage to the product that can occur during transport is at the expense and risk of the buyer Sending the product from the service center to the customer is funded by the service technician/the importer This warranty does NOT cover: • Damage or malfunctions that would occur as a result of incorrect connection, incorrect polarization,incorrect battery placement, etc. • Defects caused by improper handling of products, use of parts or equipment that is not prescribed by our specifications, unauthorized product modification, and defects mechanical damage to the product • Defects that can occur due to product fall, use of force, natural disasters (flood, fire, thunder, earthquake,...), due to battery leakage, due to unstable 220V voltage, frequent variations and/or power outages, etc. • Damage caused during transport to the customer • Products have been opened / repaired by an unauthorized person • Parts that are considered consumables such as batteries, etc. Svi Baracuda proizvodi su provjereni i testirani nakon svake faze proizvodnog procesa te imaju sve potrebne certifikate (EMC, CE,...) te podliježu sljedećim jamstvenim uvjetima: • Jamstveni rok na Baracuda proizvode je 24 mjeseca (na baterije 6 m) i počinje teći danom prodaje u trgovini • Jamstvo se može ostvariti samo uz prednoćenje originalnog računa o kupnji i uredno popunjenog jamstvenog lista sa žigom trgovine, te ako proizvod ima originalnu ambalažu i sve sastavne dijelove i opremu. • Svi nedostaci i kvarovi koji su posljedica tvorničkih grešaka i koji su nastali u jamstvenom roku i pri normalnoj uporabi proizvoda pri postavljanju svih naputaka će biti otklonjeni. Ovo jamstvo obuhvaća samo greške nastale u materijalu i izradi. • Ako se proizvod pokvari tijekom jamstvenog roka, Vas Baracuda distributor će vam proizvod popraviti ili zamijeniti nakon što ga proveri stručna osoba • Ako popravak u ovlaštenom servisu nije izvršen u roku 30 dana od primitka u servis, proizvod ćemo zamijeniti novim. U slučaju da popravak u jamstvenom roku traje duže od 15 dana, jamstveni rok se produžuje za onoliko dana koliko je popravak trajao. • Ako se ukaže potreba popravka uređaja u jamstvenom roku, kontaktirajte trgovinu u kojoj ste proizvod kupili. Ako proizvod treba poslati ovlaštenom servisu ili generalnom distributeru, molimo Vas da kompletan proizvod (sa svim dijelovima i opremom) bude zapakiran u originalnu ambalažu te da priložite sve potrebne dokumente (račun i ovjereni jamstveni list). Popravak aparata vrši se isključivo u ovlaštenom servisu uvoznika. Troškove prijevoza snosi kupac. Kupac preuzima rizik za moguća oštećenja tijekom prijevoza. Slanje proizvoda od servisa do kupca snosi serviser tj. uvoznik. Ovo jamstvo NE obuhvaća: • Oštećenja ili kvarove koji su nastali kao posljedica nepravilnog priključivanja, krive polarizacije, pogrešnog stavljanja baterija i sl. • Kvarove nastale zbog neopreznog rukovanja proizvodom, korištenja dijelova ili opreme koja nije propisana našim specifikacijama, neodoljenog modifikiranja proizvoda te kvarove nastale mehaničkim oštećenjem proizvoda • Kvarove koji mogu nastati uslijed pada proizvoda, uporabe sile, više sile tj. elementarnih nepogoda (poplava, požar, grom, potres,...) uslijed curenja baterije, uslijed nestabilnog 220V napona, čestih varijacija i/ili nestanka struje i sl. • Oštećenja nastala pri prijevozu do kupca • Proizvod koji je otvoren i/ili popravljan od strane neovlaštene osobe • Dijelove koji se smatraju potrošnicima kao što su baterije i sl.		